


IMPROVE


Particle Monitoring Network: Special Studies

Chuck McDade, Lowell Ashbaugh, &
Ann Dillner

Crocker Nuclear Laboratory
University of California, Davis
Acadia National Park, July 2005




CROCKER NUCLEAR LABORATORY
University of California, Davis




NITRIC ACID DENUDER EFFICIENCY STUDIES



San Gorgonio July 2003




CROCKER NUCLEAR LABORATORY
University of California, Davis






CSU Laboratory Tests




CROCKER NUCLEAR LABORATORY
University of California, Davis

IMPROVE HNO₃ Denuder Test Setup






Tests of New & Used Denuders




CROCKER NUCLEAR LABORATORY
University of California, Davis

Denuder Efficiency Test






Tests of Freshly Coated Denuders




CROCKER NUCLEAR LABORATORY
University of California, Davis






Interim Findings




- Denuders have a typical efficiency around 90%, but variable among individual denuders
- Efficiencies of new & used denuders do not differ appreciably ----all are around 90%
- Tests suggest that denuder capacity is sufficient for a year in the field (~ 90% efficiency is maintained throughout)



Upcoming Work



- Conduct some lab tests at lower nitric acid concentrations, closer to ambient
- Assess denuding efficiency of entire sampler (denuder plus aluminum tubing)
- Investigate improved coating techniques or different coatings (e.g., MgO)




CROCKER NUCLEAR LABORATORY
University of California, Davis

GREAT SMOKY MOUNTAINS AMMONIA STUDY




Motivation



- Ammonium measured at a few sites
 - Acidity of particles
 - Stoichiometric ratios of ammonium, sulfate and nitrate
- Difficulties in measuring ammonium
 - Contamination
 - Human breath
 - Ammonia gas in atmosphere
 - Loss of ammonium from nylon filters
- Can ammonium be accurately measured -
 - Using current IMPROVE protocol?
 - Using a reasonable modification to IMPROVE protocol?
 - Using extreme modifications to IMPROVE protocol?




Methods



- Great Smoky Mtns IMPROVE site – lots of ammonium
- Samples
 - every day
 - 24-hours
 - July 19 – August 18, 2004
- IMPROVE Samplers
 - Eight B (ions) modules
 - One set of PM2.5 modules
 - One set of speciated PM10 modules
- Techniques used to reduce contamination and loss
 - Gloves and masks, acid strips and ice in shipping container




URG Sampler




CROCKER NUCLEAR LABORATORY
University of California, Davis

- URG sampler
- Same sampling times
- Minimizes both contamination and loss
- Quantitative measure of ammonium






Strict Controls Vs IMPROVE




CROCKER NUCLEAR LABORATORY
University of California, Davis






IMPROVE vs. URG




CROCKER NUCLEAR LABORATORY
University of California, Davis






Ammonia Study



- IMPROVE protocol methods do not contaminate nylon filters with ammonium
- IMPROVE concentrations are less than URG sampler by $0.3 \pm 0.15 \mu\text{g}/\text{m}^3$
- IMPROVE is biased low – not quantitative





CROCKER NUCLEAR LABORATORY
University of California, Davis

NYLON FILTER TESTS




Nitrate measurements have shown unusual patterns at some sites






Objective




- Evaluate the difference in collection efficiency of nitrate particles on nylon filters
- IMPROVE purchases nylon filters to last about one year
 - Since December 1995, over 20 different nylon filter lots have been used






Sampling




- Sampling conducted on the roof of EUIII in Davis, CA
- 28 days of 24-hour samples, April-May 2004
- Samples begin at 2300 hr
- Eight modules sampled concurrently



Sampling Trains



CROCKER NUCLEAR LABORATORY
University of California, Davis



-Removes HNO₃(g)

-Removes NH₃(g)


-Collects particles

-Collects Nitrate


-Collects NH₃



Sampler Configuration




CROCKER NUCLEAR LABORATORY
University of California, Davis







Nylon Filters



- Four Different Nylon filter lots tested
 - Magna Nylon, GE Osmonics, BK05161B, used 08/18/01-08/30/02
 - Magna Nylon, GE Osmonics, BK09061E, used 08/30/02-01/01/04
 - Nylasorb, Pall Gelman, BNC1716, used 01/01/04-02/11/05
 - Nylon, Advantec MFS Inc., 201622, never used in IMPROVE
- Filter lots often have visible and texture differences
- All made from nylon 6,6




North Set Nylon: Comparison of Nitrate Concentration



Nitrate concentration measured using four different nylon filters without a Teflon prefilter



South Set Nylon: Comparison of Nitrate Concentration




Nitrate concentrations measured using four different nylon filters preceded by a Teflon filter (note difference in concentration scale)






Mean Total Nitrate Concentration




CROCKER NUCLEAR LABORATORY
University of California, Davis






Conclusions



- Nylon filters tested were virtually identical in their nitrate collection characteristics.
 - We were unable to test filters used prior to August 2001 because they were no longer available.
 - The few nitrate differences that were observed occurred when one set of samplers did not run all 24 hours – differences were consistent with higher concentrations at night and lower concentrations during the day.




CROCKER NUCLEAR LABORATORY
University of California, Davis

MOBILE LABORATORY



IMPROVE Mobile Laboratory



- Cooperative effort – UCD & CSU
- To be used for special studies
- Delivery expected late summer 2005


Mobile Lab Details

- International truck + 20' custom truckbody
- Three power options: landline, onboard generator, inverter/battery system
- Air-ride suspension for smooth ride for delicate instrumentation
- Rear power liftgate for loading instruments
- Underbody storage boxes for pumps, etc.
- Split design-chemistry lab and aerosol lab
- Modular, reconfigurable instrumentation






“Green” Diesel Retrofit



- Future retrofit of continuously regenerating catalyzed particulate filter
- Will be cleaner than CNG (w/low sulfur diesel in 2007)
- Diesel also uses 40-60% less fossil fuel per mile than gas engines
- Other diesel benefits-greater engine longevity (0.5 million miles) and more torque
- Also allows use of electrical generator

Green Diesel Emissions



- Big improvement, especially in PM emissions
- Important for on-road and stationary sampling using self-generator power

Mobile Lab Instrumentation

Online Ions and Carbon



Dry Particle Sizing System



Trace Gases (CO, O3, NH3/NO/NO2)




- Light Scattering, Microbalance, MOUDI, IMPROVE Sampler, Met Station

HTDMA-CSU Version 3.0




HTDMA

Control and
Measurement
Electronics,
Pneumatics,
Pumps, Aerosol
Generation










IMPROVE vs. STN SAMPLER COMPARISON




Scope of the Analysis



- New data recently available, from Year 2 of comparison
- Broad-brush analysis today, focusing on Year 1 versus Year 2
- More detailed analyses to follow later in 2005




STN/IMPROVE Intercomparison




CROCKER NUCLEAR LABORATORY
University of California, Davis

Operated According to Each Network's Protocols






What do we know?




- Year 2 looks much like Year 1
- Major components of the aerosol agree well between STN and IMPROVE
- OC differs because techniques are different
- Many soil elements differ (due to cutpoints?)
- Comparing near the MDL can be misleading, and many measurements are near the MDL





Major Aerosol Components



Fine Mass (PM2.5)




CROCKER NUCLEAR LABORATORY
University of California, Davis







Sulfur




CROCKER NUCLEAR LABORATORY
University of California, Davis







Sulfate




CROCKER NUCLEAR LABORATORY
University of California, Davis








Nitrate



CROCKER NUCLEAR LABORATORY
University of California, Davis






Elemental & Organic Carbon

Techniques differ between STN & IMPROVE



- Temperature profiles for sample heating not identical
- IMPROVE corrects for artifacts, STN does not



Elemental Carbon




CROCKER NUCLEAR LABORATORY
University of California, Davis








Organic Carbon



CROCKER NUCLEAR LABORATORY
University of California, Davis






Soil Elements

Some differences; IMPROVE generally higher



- Different cutpoints may be the cause (to be investigated)



Calcium




CROCKER NUCLEAR LABORATORY
University of California, Davis







Iron




CROCKER NUCLEAR LABORATORY
University of California, Davis







Silicon






CROCKER NUCLEAR LABORATORY
University of California, Davis








Silicon: Arizona Sites Highlighted





Silicon at Phoenix: Large Deviations are Episodic






For Some Elements Many Measurements are Near their MDL

Data can be noisy near the MDL



- Comparison behavior can be masked by noise when relative errors are high
- Screening out low concentrations can help



Chromium




CROCKER NUCLEAR LABORATORY
University of California, Davis







Chromium: >3 x MDL only




CROCKER NUCLEAR LABORATORY
University of California, Davis







Manganese




CROCKER NUCLEAR LABORATORY
University of California, Davis







Manganese: >3 x MDL only




CROCKER NUCLEAR LABORATORY
University of California, Davis







Selenium




CROCKER NUCLEAR LABORATORY
University of California, Davis







Selenium: >3 x MDL only




CROCKER NUCLEAR LABORATORY
University of California, Davis






For the Future




- Develop understanding of differences in measurements (e.g., soil elements)
- Apply further statistical techniques
 - Performance versus expectations
 - Means, medians, standard deviations
- Explore Year 1-to-Year 2 differences
- Add data from current sites and from urban sites established in 2004



IMPROVE vs. STN XRF COMPARISON



XRF Systems



CROCKER NUCLEAR LABORATORY
University of California, Davis

STN (RTI)


- Anode X-ray tube
 - High flux rhodium anode X-ray tube
 - Five excitation conditions
- Lithium-drifted silicon detector
- Vacuum system

IMPROVE

- Anode X-ray tube
 - High flux Copper and Molybdenum anode X-ray tubes
- Lithium-drifted silicon detector
- In air and He environment systems




RTI Round Robin Filters




- Over 6 months old but less than 1 year
- Range of elements above analytical uncertainties
- Range of concentrations
- No data validity flags or codes
- In good condition, visually

Round Robin Results vs Median All Elements




Round Robin Results vs Median Iron only






IMPROVE analysis of the STN round robin filters



- Adaptation of STN 47mm Teflon filters for IMPROVE XRF analysis
- Analysis of 47mm Teflon laboratory blanks
- Analysis of Round Robin filters



Slide Mounts




CROCKER NUCLEAR LABORATORY
University of California, Davis

STN (47mm)


IMPROVE (25mm)




XRF analysis – by filter ID, Significant detection of all elements




XRF analysis – by element, Significant detection – full scale




XRF analysis – by element, Significant detection – soil scale



XRF analysis – by element, Significant detection – tracer scale




XRF analysis – by element, near detection limits






Conclusions



- STN samples are within specifications of IMPROVE XRF analysis system
- General good agreement between STN and IMPROVE XRF analysis. Of the significant detection:
 - 16 Elements reported very good precision



Next Steps



- Analysis of Micromatter standards
- Analysis of NIST samples
- Reanalysis of same filters by RTI
- Developing protocols for round robin tests between IMPROVE and STN networks

